

Pin #1 -- [Chasis]* -- {IEC GRND}
Pin #2. -- [Output+ (+4)]*{xlr male pin2}
Pin #3 -- [blank]
Pin #4 -- [Output low]* {xlr male pin3}
Pin #5 -- [Audio Grnd]*
Pin #6 -- [blank]
Pin #7 -- [blank]
Pin #8 -- [Input Low/ GRND]* {xlr female pin3}
Pin #9 -- [blank]
Pin#10 -- [Input Hi +4dbu]* {xlr female pin2)
Pin#11 -- [blank] Gain Adjust
Pin#12 -- [+16vdc]*
Pin#13 -- [GRND]*
Pin#14 -- [-16vdc]*
Pin#15 -- [+48vdc Phantom]*